


## AS5 - AC Sliding Panel Diagram



Function options		Description	Application Notes	
JP1	Soft Start	On	Soft Start enabled	Firmware Detection of signal, if no signal, run at one speed only
		Off	No Soft Start function	
JP2	Limit Switch	Normally Close	Select if Normally Close function required	
		Normally Open	Select if Normally Open function required	
JP3	Brake	On	AC Reverse Stop Signal	
		Off	No brake function	
JP4	Auto Close	30 Second	Gate auto close after remained open for 5 seconds	
		Off	Select if function not required	
JP5	Light	Follow	Light status & motor movement in parallel	Light is on when motor is on, light is off when motor is stopped When gate is closed, light will be off after 60 seconds
		Delay	Light status is set to be off after a delay of 60 seconds	
JP6	Photo Beam	On	Select if Photo Beam Sensor Available	Safety feature, Gate will auto open when collision occur with Photo Beam Sensor available, & function on.
		Off	No Sensor available	