



BARRIER GATE

BR600 SERIES SPARE PART AND ACCESSORIES





BR6AT40

**REPLACEMENT 3/4/4.5
METER TELESCOPIC
ALUMINUM ARM (8.6CM)**


FOR BR618T & BR630T



BR6AT60

**REPLACEMENT 6 METER
TELESCOPIC ALUMINUM
ARM (8.6CM)**


FOR BR660T



BR6ATFE

**REPLACEMENT FENCE ARM
HORIZONTAL HEIGHT
0.9 METER**

FOR BR660T_FE



BR6AT90

**REPLACEMENT FOLDING
ARM 90°**

4 METER

FOLDED HEIGHT 2.3 METER




BR6AT180

**REPLACEMENT FOLDED
ARM 180°**


3.67 METER

FOLDED HEIGHT 2.3 METER



BR6AS40LED

**4 METER STRAIGHT ARM
WITH LED LIGHT RUBBER
LINING**



BR6AS60LED

**6 METER STRAIGHT ARM
WITH LED LIGHT RUBBER
LINING**



BR_SIGNBOARD

SIGNBOARD

- STOP (RED)
- VISITOR (BLUE)
- RESIDENT (GREEN)



ARM SUPPORT POLE

- FOR STRAIGHT ARM USE
- STANDARD HEIGHT
760 - 1050MM ADJUSTABLE



MAG BR6T

BARRIER MOTOR ONLY

MOTOR GEAR BOX

For BR618T - Left / Right

For BR630T - Left / Right

For BR660T - Left / Right



MAG BR6T

ARM BRACKET WITH SHAFT

ARM BRACKET WITH SHAFT

For BR618T - Left / Right

For BR630T - Left / Right

For BR660T - Left / Right

- BEARING BLOCK X2
- BALANCE CRANK X1
- MECHANISM LIMIT X1



BR6_SPRING

COUNTER WEIGHT SPRING

RED

For 4 meter arm use

BLUE

For 4.5 meter arm use

YELLOW

For 6 meter arm use


BR6T_CNTRL

**CONTROLLER BOARD
FOR BR618T / BR630T / BR660T**


LD01


**SINGLE CHANNEL
LOOP DETECTOR
(AC230)**


BRD03


**DUALRAY AND LED
DISPLAY TRAFFIC
DETECTOR**


C240AC

**LPS AC230 SURGE
PROTECTOR**


MD-4CCU

**12VDC WITH RS485
(DATA / SIGNAL)**


BR_FL

**STRIP FOAM LINING
2 METER PER STRIP FOAM LINING
FOR BARRIER ARM (18 X 18 MM)**


BR_PB2

**DOUBLE PUSH BUTTON
WITH BOX
(START & STOP)**


BR_PB3

**TRIPLE PUSH BUTTON
WITH BOX
(REV, FOR & STOP)**


TL100

**TWO WAY TRAFFIC
LIGHT
RED & GREEN LIGHT
(AC220)**


BR6T_BALANCE CRANK
BALANCE CRANK

FOR BR618T / BR630T / BR660T


BR6T_DRIVE CRANK
DRIVE CRANK

 FOR BR618T / BR630T / BR660T
 (CAN USE FOR BR5 SERIES
 BARRIER)

BR6T_SWAY CRANK
SWAY CRANK

FOR BR618T / BR630T / BR660T


BR6T_INITIATIVE
INITIATIVE CRANK

FOR BR618T / BR630T / BR660T


MAG BR6T
**MECHANISM LIMIT
 (SHOCK ABSORPTION
 CRANK)**

FOR BR618T / BR630T / BR660T


MAG BR6T
BEARING CRANK

FOR BR618T / BR630T / BR660T


MAG BR6T
**PLUG BOLT
 (4 PCS PER SET)**


FOR BR618T / BR630T / BR660T


BR6T_BASEBKT
**BASE MOUNTING
 U-CHANNEL BRACKET**

FOR BR618T / BR630T / BR660T


BR6T_HOUSING
BR600 SERIES HOUSING

- TOP COVER + BODY (GREY)
- INCLUDED CAMP LOCK & KEY
- BLUE PLATE WITH HOLDER

**BR6T_LNSR****LIMIT SWITCH
SENSOR BOARD**

FOR BR618T / BR630T / BR660T

**BR6T_MOTOR COUNTER SENSOR****MOTOR COUNTER
SENSOR**

FOR BR618T / BR630T / BR660T

**BR5_CAP****CAPACITOR FOR
BARRIER GATE USE****MAG BR6T****FAN FOR MOTOR
GEAR BOX**

FOR BR618T / BR630T / BR660T

**MAG BR6T****NYLON YELLOW
STOPPER (BIG SIZE)**

FOR BR618T / BR630T / BR660T


**MAG BR6T****BLUE ACRYLIC PLATE
FOR BARRIER HOUSING**

FOR BR618T / BR630T / BR660T

**MAG BR6T****MANUAL RELEASE PIPE
FOR BARRIER HOUSING**

FOR BR618T / BR630T / BR660T

**BR6T_CLKEY****CLKEY MANUAL CLUTCH
RELEASE KEY (1 KEY)**

**MAG BR6T****ARM LONG SCREW
WITH 2 PLATE**FOR BR618T / BR630T / BR660T
TELESCOPIC ARM**MAG BR6T****ARM HOLDER BRACKET
(2 PCS)**

FOR BR618T / BR630T / BR660T

**MAG BR6T****ARM COVER (A)**

FOR BR618T / BR630T / BR660T

**MAG BR6T****ARM COVER (B)**

FOR BR618T / BR630T / BR660T

**MAG BR6T****ARM COVER (C)**

FOR BR618T / BR630T / BR660T

**MAG BR6T****NYLON BRUSH + C-CLIP
FOR SWAY CRANK USE**

FOR BR618T / BR630T / BR660T

**MAG BR6T****C-CLIP FOR INITIATIVE
CRANK****MAG BR6T****METAL PIN FOR
INITIATIVE CRANK**

FOR BR618T / BR630T / BR660T

**MAG BR6T****POSITION MAGNET SENSOR
FOR INITIATIVE CRANK**

FOR BR618T / BR630T / BR660T

**MAG BR6T****BALANCE CRANK SCREW**

FOR BR618T / BR630T / BR660T
METAL BALSC

**MAG BR6T****INITIATIVE CRANK
(TOP SCREW)**

FOR BR618T / BR630T / BR660T
INISC-TOP

**MAG BR6T****INITIATIVE CRANK
(BUTTON SCREW)**

FOR BR618T / BR630T / BR660T
INISC-BOT

**MAG BR6T****MANUAL RELEASE KITS**

FOR BR618T / BR630T / BR660T

**MAG BR6T****FOLDING ARM SCREW**

FOR BR618T / BR630T
FOLSC-FI

**MAG BR6T****FOLDING ARM SCREW**

FOR BR618T / BR630T
FOLSC-SU

**MAG BR6T****SPRING SCREW**

FOR BR618T / BR630T / BR660T